

P2P51 G7 Calibration Target

To use the P2P51 target with i1Profiler follow these steps:

1. Print the target P2P51.tif
2. Open i1Profiler
3. In the **Workflow Selector** click "**Measure Reference Chart**"
4. Click **Load** and open the "P2P51.txt" file
5. Start the measurement